



**Power ON:**

1. Set  $V_{G1} = -2$  V and Turn ON.
2. Set  $V_{G2} = +5$  V and Turn ON.
3. Set  $V_{DD} = 12$  V and Turn ON.
4. Increase  $V_{G1}$  to desired  $I_{DD}$ .
5. Turn ON RF signal.

**Power OFF:**

1. Turn OFF RF signal.
2. Decrease  $V_{G1}$  to  $-2$  V.
3. Turn OFF  $V_{DD}$ .
4. Turn OFF  $V_{G2}$ .
5. Turn OFF  $V_{G1}$ .

Mini-Circuits

THIS DOCUMENT AND ITS CONTENTS ARE THE PROPERTY OF MINI-CIRCUITS. EXCEPT FOR USE EXPRESSLY GRANTED, IN WRITING, TO ITS VENDORS, VENDEE AND THE UNITED STATES GOVERNMENT, MINI-CIRCUITS RESERVES ALL PROPRIETARY DESIGN, USE, MANUFACTURING AND REPRODUCTION RIGHTS THERETO. THESE CONTENTS SHALL NOT BE USED, DUPLICATED OR DISCLOSED TO ANY OUTSIDE PARTY, IN WHOLE OR IN PART, WITHOUT WRITTEN PERMISSION OF MINI-CIRCUITS.

ALL DIMENSIONS ARE IN INCHES EXCEPT OTHERWISE SPECIFIED

SIZE A	CODE IDENT 15542	DRAWING NO: TB-PMA5-83-2WC-20+	REV: B
-----------	---------------------	-----------------------------------	-----------

FILE: WTB-PMA5-83-2WC+	SCALE: 4:1	SHEET: 7 OF 7
------------------------	------------	---------------

ASHEETA2.DWG REV:A DATE: 01/12/94